

# PARTNER LCD

## P1832 LCD QUICK REFERENCE

This card provides basic operation of the most commonly used features on your security alarm system. If you need more information, please consult your owner's manual or call Amherst Alarm at (716) 632-4600.

[www.AMHERSTALARM.COM](http://www.AMHERSTALARM.COM)



### QUICK REFERENCE

Arm the system	<p><b>Stay</b> - Will arm the perimeter only*</p> <p><b>Away</b> - Will arm the entire system</p>
Function Buttons	<p><b>Chime</b> - Press and hold to toggle between door chime on and off</p> <p><b>Bypass</b> - Press [*][1], use the scroll keys [&lt; &gt;] to find the zone to be bypassed            Press [*]            Press [#] to exit</p> <p><b>Exit</b> - Allows you to leave the premises through your delay zone without having to disarm and rearm the system. Press and hold until beep.</p> <p>*Stay will typically bypass the interior motion sensors, ask your installer for a specific configuration.</p>
Disarm the system	Enter your 4 digit security code
Viewing Trouble Conditions	Press [*][2] Use the scroll keys [< >] to view the troubles Press [#] to exit
Silence Troubles	Press any button on the keypad
Viewing Alarm Memory	Press [*][3] Use the scroll keys [< >] to view Press [#] to exit
Adding, Changing, or Deleting an Access Code	Press [*][5][Master Code] Use scroll keys [< >] to find user code to be edited Press [*] to select To Add: Enter 4 digit code To Change: Enter new 4 digit code To Delete: Press [*] Press [#] to exit *Master code is user code 40
Setting Date/Time	Press [*][6][Master Code][1] Enter time (0:00 - 23:59) Enter Date (mm/dd/yy) Press [#] to exit
Resetting a smoke detector	Clear area of all smoke Enter your 4 digit code to silence the siren Press
Use of panic buttons	Press and hold for 2 seconds
Duress Code	Press 4444 for a silent panic alarm (Unless your duress code has been changed)

# EMERGENCY PROCEDURES

In case of...	What to do...	What happens...
Accidental Alarm Activation	<ol style="list-style-type: none"> <li>1. Enter your access code</li> <li>2. Wait for the Monitoring Response Center to call you</li> </ol>	<ol style="list-style-type: none"> <li>1. Alarm will sound until a valid access code is entered</li> <li>2. Give the dispatcher your password</li> </ol>
Fire Alarm	<ol style="list-style-type: none"> <li>1. Leave immediately. If you are already outside DO NOT re-enter the building</li> <li>2. Follow your fire evacuation plan</li> <li>3. Call 911 or fire department from a safe distance as an extra precaution</li> </ol>	<ol style="list-style-type: none"> <li>1. Alarm will sound</li> <li>2. The system will automatically notify the Monitoring Response Center, who will dispatch the fire department</li> </ol>
Burglary Alarm	<ol style="list-style-type: none"> <li>1. If you are already outside, DO NOT re-enter the building.</li> <li>2. Call 911 or police department from a safe distance as an extra precaution</li> <li>3. If you are inside the building and can leave safely, do so.</li> </ol>	<ol style="list-style-type: none"> <li>1. Alarm will sound</li> <li>2. The system will automatically notify the Monitoring Response Center, who will verify the alarm before dispatching the police.</li> </ol>
CO Alarm	<ol style="list-style-type: none"> <li>1. Immediately move outdoors or to an open window/door</li> <li>2. Call emergency services as an extra precaution</li> </ol>	<ol style="list-style-type: none"> <li>1. Alarm will sound</li> <li>2. The system will automatically notify the Monitoring Response Center, who will dispatch emergency services</li> </ol>

## WHAT THE SOUND MEANS

High volume, high pitched pulsing	FIRE
Rapidly alternating high/low pitched tone	BURGLARY or TAMPERING
Beep every 8 -10 seconds	SYSTEM TROUBLE CONDITION
4 quick beeps followed by a 5 second pause	CARBON MONOXIDE PRESENT



WATCHING OUT FOR WNY SINCE 1984

