

PARTNER IMPASSA

SCW9057 LCD QUICK REFERENCE

This card provides basic operation of the most commonly used features on your security alarm system. If you need more information, please consult your owner's manual or call Amherst Alarm at (716) 632-4600.



www.AMHERSTALARM.COM



QUICK REFERENCE

Arm the system	<p>Stay - Will arm the perimeter only*</p> <p>Away - Will arm the entire system</p>
Function Buttons	<p>Chime - Press and hold to toggle between door chime on and off</p> <p>Bypass - Use the scroll keys [< >] to find the zone to be bypassed</p> <p>Press [*]</p> <p>Press [#] to exit</p> <p>Exit - Allows you to leave the premises through your delay zone without having to disarm and rearm the system</p> <p>*Stay will typically bypass the interior motion sensors, ask your installer for a specific configuration.</p>
Disarm the system	Enter your 4 digit security code
Viewing Trouble Conditions	<p>Press [*][2]</p> <p>Use the scroll keys [< >] to view the troubles</p> <p>Press [#] to exit</p>
Silence Troubles	Press any button on the keypad
Viewing Alarm Memory	<p>Press [*][3]</p> <p>Use the scroll keys [< >] to view</p> <p>Press [#] to exit</p>
Adding, Changing, or Deleting an Access Code	<p>Press [*][5][Master Code]</p> <p>Use scroll keys [< >] to find user code to be edited</p> <p>Press [*] to select</p> <p>To Add: Enter 4 digit code</p> <p>To Change: Enter new 4 digit code</p> <p>To Delete: Press [*]</p> <p>Press [#] to exit</p> <p>*Master code is user code 40</p>
Setting Date/Time	<p>Press [*][6][Master Code][1]</p> <p>Enter time (0:00 - 23:59)</p> <p>Enter Date (mm/dd/yy)</p> <p>Press [#] to exit</p>
Resetting a smoke detector	<p>Clear area of all smoke</p> <p>Enter your 4 digit code to silence the siren</p>
Use of panic buttons	Press and hold for 2 seconds
Duress Code	Press 4444 for a silent panic alarm (Unless your duress code has been changed)

EMERGENCY PROCEDURES

In case of...	What to do...	What happens...
Accidental Alarm Activation	<ol style="list-style-type: none"> 1. Enter your access code 2. Wait for the Monitoring Response Center to call you 	<ol style="list-style-type: none"> 1. Alarm will sound until a valid access code is entered 2. Give the dispatcher your password
Fire Alarm	<ol style="list-style-type: none"> 1. Leave immediately. If you are already outside DO NOT re-enter the building 2. Follow your fire evacuation plan 3. Call 911 or fire department from a safe distance as an extra precaution 	<ol style="list-style-type: none"> 1. Alarm will sound 2. The system will automatically notify the Monitoring Response Center, who will dispatch the fire department
Burglary Alarm	<ol style="list-style-type: none"> 1. If you are already outside, DO NOT re-enter the building. 2. Call 911 or police department from a safe distance as an extra precaution 3. If you are inside the building and can leave safely, do so. 	<ol style="list-style-type: none"> 1. Alarm will sound 2. The system will automatically notify the Monitoring Response Center, who will verify the alarm before dispatching the police.
CO Alarm	<ol style="list-style-type: none"> 1. Immediately move outdoors or to an open window/door 2. Call emergency services as an extra precaution 	<ol style="list-style-type: none"> 1. Alarm will sound 2. The system will automatically notify the Monitoring Response Center, who will dispatch emergency services

WHAT THE SOUND MEANS

High volume, high pitched pulsing	FIRE
Rapidly alternating high/low pitched tone	BURGLARY or TAMPERING
Beep every 8 -10 seconds	SYSTEM TROUBLE CONDITION
4 quick beeps followed by a 5 second pause	CARBON MONOXIDE PRESENT

For Service Contact:
Amherst Alarm, Inc.
 2361 Wehrle Drive
 Amherst, NY 14221
(716) 632-4600



WATCHING OUT FOR WNY SINCE 1984

