NEO LCD KEYPAD

This card provides basic operation of the most commonly used features on your security alarm system. If you need more information, please consult your owner's manual or call Amherst Alarm at **(716) 632-4600**.



www.AmherstAlarm.com

QUICK REFERENCE			
Arm Stay	(STAY) for 2 seconds		
Arm Away	(AWAY) for 2 seconds		
Turn Chime On/Off	CHIME for 2 seconds OR [Access Code] + (**) 4		
Reset Smoke Detectors	reset for 2 seconds OR * 7 2		
Quick Arm/Exit	EXIT for 2 seconds OR 🛣 0		
Disarm the system	Enter your 4 digit access code		
Night Arm	(When armed in Stay Mode) 🖈 1		
No-Entry Arming	(When armed) \star 9		
Duress Code	(Unless your duress code has been changed)		
Bypass Zones	(* 1 [3 Digit Zone Number]		
Set Date & Time	(* Code] + (* O (* Level Time) (* Le		
Add User / Change User Code	(* 5 + [Master Code] + > [Select User] (* *) [Enter Code] # #		
View Troubles	*2 + <>		
View Alarms	* 3 + < >		
Delete User	★ 5 + [Master Code] + [Select User] ★ ★ # #		
User Settings	(Bright Control and Buzzer Control)		

^{*} Master Code is User 01. Duress Code is User 33.

EMERGENCY PROCEDURES				
In case of	What to do	What happens		
Accidental Alarm Activation	Enter your access code Wait for the Monitoring Response Center to call you	Alarm will sound until a valid access code is entered Give the dispatcher your password		
Fire Alarm	Leave immediately. If you are already outside DO NOT re-enter the building Follow your fire evacuation plan Call 911 or fire department from a safe distance as an extra precaution	Alarm will sound The system will automatically notify the Monitoring Response Center, who will dispatch the fire department		
Burglary Alarm	If you are already outside, DO NOT re-enter the building. Call 911 or police department from a safe distance as an extra precaution If you are inside the building and can leave safely, do so.	Alarm will sound The system will automatically notify the Monitoring Response Center, who will verify the alarm before dispatching the police		
CO Alarm	Immediately move outdoors or to an open window/door Call emergency services as an extra precaution	Alarm will sound The system will automatically notify the Monitoring Response Center, who will dispatch emergency services		

WHAT THE SOUND MEANS

High volume, high pitched pulsing	FIRE	
Rapidly alternating high/low pitched tone	BURGLARY or TAMPERING	
Beep every 8 -10 seconds	SYSTEM TROUBLE CONDITION	
4 quick beeps followed by a 5 second pause	CARBON MONOXIDE PRESENT	

For Service Contact:

Amherst Alarm, Inc. 2361 Wehrle Drive Amherst, NY 14221 (716) 632-4600



